

ACM12

Addendum V4.66

P ▲ R ▲ D O X™

The following information has not been included in the ACM12 Installation manual. The information detailed in this addendum applies to the ACM12 Module V4.66 or higher.

Added Utility Key to PGM Activation

Section	Data	Description	Default
[011]	__/_	PGM Activation	00
00 : Arm 01 : Follow Door Unlock Schedule 02 : Follow Access Granted (will be activated for the unlock period) 03 : Follow Door Forced State 04 : Follow Door Left Open Warning / Alarm 05 : Utility Key 1 06 : Utility Key 2 07 : Utility Key 3 08 : Utility Key 4 09 : Utility Key 5 10 : Utility Key 6 11 : Utility Key 7 12 : Utility Key 8 13 – 99 : Future Use			

Added Re-Lock Option

Section [013]			
Option		OFF	ON
[1]	Re-lock option	On door opening	On door closure
[2] - [8]	For Future Use	-	-

